





3300000






1




2


2




3




4




5




6




7




8




9




10




11




12



13




14







15




16




17




18




19



20



21





1




2



**3**



**4**





1



2




3x


5




6




7




8




9




10




11




12




13




14




15



16



17





2x  
300521



8x  
300321



4x  
235721



6x  
301021



**Customer Service**

**Kundenservice**

**Service Consommateurs**

**Servicio Al Consumidor**

[www.lego.com/service](http://www.lego.com/service) or dial



00800 5346 5555 :



1-800-422-5346 :



4x  
300121



6x  
300921



6x  
4504379



2x  
4121934



16x  
4501534



6x  
4163087



8x  
366021



7x  
303721



5x  
302321



4x  
302221



4x  
243121



8x  
371021



2x  
4560179



1x  
4243814



2x  
346021



2x  
303221



4x  
242021



4x  
300524



3x  
300324



4x  
4264338



2x  
302224



1x  
4537927



9x  
4211183



3x  
4219726

