



40090







1x

1



1x



2x

2



1x



1x

3



2x

4





1x



2x

5





6x



2x

6





1x



1x

7




1x



2x

8





2x




1x

9



2x

10





1x



1x

11



2x



1x

12





4x



1x



2x



2x

13

1



2



3



4






14



1



2



2x




1x



1x

1



2x



1x

2



2x

3





1x



1x

4



2x



1x



1x

5



3x

6



2x



2x

7





2x



2x

8



1x



1x



2x

9





2x



1x

10



1x



2x

11





2x



2x

12



1x



1x



2x


13



1



2





2x




2x



2x

14

1



2



2x



15





2x



2x



1x



2x



2x



1x

16

1




2




3





4





2x



2x



1x



2x



2x



1x

17

1



2



3





1



2



4





2x



2x



1x



4x



4x



4x



4x




16x

18

1








2



3









2x
6029156



2x
4224792



4x
300426



2x
235726



6x
407026



2x
4533771



2x
4548180



2x
6069000



6x
366026



3x
303926



10x
6047276



1x
379426



9x
306926



1x
302226



8x
242026



2x
302026



2x
6052126



8x
4515368



1x
4616245



4x
4160025



8x
4273590



4x
302228



1x
4619599



16x
4504371



4x
4188771



4x
4177932



4x
4125278



7x
6015344



2x
6028812



4x
4598526



2x
4211088



1x
4211103



2x
4504378



2x
4567887



2x
4648256



6x
4211063



4x
4211094



3x
4211043



2x
6031883



1x
4517996



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346

