




40122








1




2





2x

1




4



1x

2




1x



2x

3






2x



2x

4



6




1x



2x

5






4x



2x

6



1x





1x




1x

7






8



8



9





6x

10




2x



2x


11






12

1



2



3



4




5





2x

13





2x



2x

14





1x



1x




1x



1x

15



1x



2x

16





4x




2x




2x

17

1



2



2x





2x



2x




1x



18



2x




19








20





1x

21




2x



2x

22





1x

23



20



2x



2x

24





2x



2x

25



2x



2x

26



2x




1x



1x

1



1x

2





1x



1x



1x

3



2x

4






1x



1x

5




2x



2x

6





2x

7




1x



1x

8







Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346



LEGO and the LEGO logo are trademarks of the/son des marques
de commerce du/son marcas registradas de LEGO Group.
©2015 The LEGO Group. 6123834 / 6123835