



40139



LEGO.com/creator

1



2



3




4





2x

1





1x



1x



1x

2



4



2x



4x



2x

3





2x



4x



2x

4



6



1x



1x



1x

5





2x



2x

6



8



1x

7





2x


8



10




2x



2x

9






2x



1x



1x

10





2x



4x



2x

11



2x



1x



1x



2x

12





4x




4x



2x

13





2x



2x



2x

14





3x



6x



6x



6x



6x



6x

15

1



2



3



4



5



6



3x





1x



1x



2x

16





6x



2x

17





1x



1x



2x

18






2x



4x

19





1x



2x



2x

20





1x

1



1x

2





2x

3






2x



1x


4





1x

5



21





2x



8x



6x



6x

22

1



2



3



2x





1x



1x



2x

23





3x



1x



1x



1x



1x




1x



1x

24



2





1x



1x



1x

25






6x



6x



26



6x



2x



1x



27



36



1x



1x



1x

28





2x



4x

29





1x



4x



2x

30





4x

31



40



2x

32





1x

33





4x

34





2x



2x

35






1x



1x

36






1x



1x

1





1x



1x



1x



1x

2





2x



2x



2x


3





4x

4






2x



1x

5






1x



2x


6






2x

7




8



37






1x



1x

1





1x



1x



1x

2





2x



2x



2x


3





4x

4






2x



1x

5






1x



2x


6






2x

7



8



38



39





1x



1x

40

1



2





1x



1x



1x




2x



1x

41

1




2



3



4



42





1x



1x



2x



2x



2x

43







10x
614101



7x
6037277



16x
4518400



1x
625401



8x
4249563



8x
6046381



5x
371001




1x
6023806



1x
302001




2x
346001



3x
303401



4x
6057460



2x
303601



1x
244501



1x
6093053



4x
4565324



1x
390001



16x
6057986



12x
6058135



15x
4656783



8x
6055309



8x
4666322



6x
6060731



3x
4211151



1x
4565394



1x
4579690



2x
4211247



2x
4216945



2x
4217562



1x
6055871



1x
4113233



1x
4548180



5x
393726



2x
4644456



1x
302226



3x
302426



10x
4569058



3x
4619599



1x
403228



4x
4646860



6x
4217436



1x
4537251



1x
4621557



4x
6061678



1x
6092592



2x
6092766



1x
307021



11x
614121



6x
6092565



1x
609121



6x
3000841



2x
6092770



1x
6065504



4x
4646865



1x
6073040



6x
3000844



2x
6078279



4x
6053876



1x
6055381



4x
6060795



1x
4580007



1x
4654582



5x
4211881



1x
6031883



3x
6092768



1x
6074906



2x
6078932



4x
4566522



1x
6062386



1x
6019608



6x
4266417



2x
6102986



1x
6069948



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555



: 1-800-422-5346