



40141



EXCLUSIVO
only at
ToysRus

EXCLUSIF
uniquement chez
ToysRus

EXCLUSIVO
sólo en
ToysRus

1



2



3




4





1x

1




1x



2x

2






1x



1x

3



4



4x

4






1x



1x

5




2x



1x

6





1x

7



6



1x



1x



1x



1x




1x

1

1




2



3







1x

1x


1





1x

2



1x




1x



2x

3






1x



1x

4






3x



1x

5



1x




2x



1x

6





1x



1x




2x



2x

7






1x



3x

8



1x



1x




3x



1x

9





2x




1x



2x

10






1x



2x

11




2x



4x

12







2x



4x


13





2x

14






3x



1x

15






2x



2x

16






2x



6x

17






3x



1x

18






1x



4x

19







2x



2x

20





1x



2x



2x

21






2x



2x

22





1x



1x

23





2x



4x

24





2x




4x



2x

25



2x




2x



2x

26





1x



3x

27





2x




2x



2x

28



2x



2x

29





3x



4x

30





1x



2x

31





2x

32





2x



2x



2x

33





3x



4x

34





1x



2x

35





2x



2x

36





3x



2x

37





1x



4x

38





2x

39





2x



3x

40






2x

2x

2x

1x

41







1x

42

1



2





1x
302321



4x
614126




2x
4632571



1x
302426



4x
4121715



2x
303526



12x
4619599



2x
302428



4x
302328



2x
6102986



3x
6051921



2x
4163917



24x
6052994



2x
6070905



4x
4183133



2x
6078932



4x
4539099



2x
4529242



1x
4224243



1x
4538950



3x
302401



1x
4504369



2x
300501



2x
307001



1x
486501



2x
3200001



7x
300401



2x
4249563



3x
4558168



2x
362301



1x
3000840



2x
4244362



6x
4645394



4x
4167842



6x
6054554



3x
4210719



1x
6000311



2x
4568734



1x
4211053



3x
4211001



4x
4211415



2x
4521921



1x
4211398



12x
6000066



1x
4211429



1x
4560183



3x
4211395



1x
4211438



1x
4496699



2x
4125253



8x
4159553



4x
6060850



2x
6092587



5x
4160483



2x
4113917



5x
4121921



4x
4113233



5x
4118790



7x
4114309



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



00800 5346 5555 :



1-800-422-5346 :







40141



40142



40143



40144

