



# Disney



43205



5




**WARNING:** CHOKING HAZARD.  
Toy contains small parts and a small ball.  
Not for children under 3 years.



1



2





2x

1




**AVERTISSEMENT : RISQUE D'ÉTOUFFEMENT.**

Le jouet contient des petites pièces ainsi qu'une petite boule.  
Il ne convient pas aux enfants de moins de 3 ans.



**ADVERTENCIA: PELIGRO DE ASFIXIA.**


Juguete que contiene partes pequeñas y una pelota pequeña.  
No recomendado para niños menores de 3 años.





2x


2





1x

3






1x



1x


4





2x


5






1x


6








7












10





11





1x





2x




1x



# 12





13





14








1x



1x

15







1x





1x


16






17





18







1x




1x

19







20



2










1x



21








22




23






2x

24



1x


25





2x

26




1x

27




28





1x

29






1x



1x

30




1





2






31






32


1




2




3




4












33





1x

34







1x


35

1






2





36





1x

37





2x

38







2x




2x

39




2x






40






41

1



2








1x




1x


42





43






3x


44






1x

45







46






1x



47



1x

48





4x

49




1x



1x

50



51






3x

52





53





1x

54






1x



1x

55









1x



1x


56






57


1




2




3



4











Rebuild  
the  
world™



Disney  
**FROZEN**



43197

Disney  
**PRINCESS**



43208

Disney  
**PRINCESS**



LEGO.com/disney

43207

Disney  
**FROZEN**



4+


43204

Disney  
**PRINCESS**



43206

©Disney



Rebuild  
the  
world™



LEGO and the LEGO logo are trademarks of the/sont des marques de commerce du/  
son marcas registradas de LEGO Group. ©2022 The LEGO Group. All rights reserved/  
Tous droits réservés/Todos los derechos reservados. 6429782

©Disney