



CITY

60084

 LEGO.com/city






1x

1



1x


2





3x

3




4



1x

4






2x



1x

1




2x





2x

2



2x





1x

3




6





1x



4




2x

5






1






1x

2



2x


3





2x

4






1x




2x

5



1x

6






2x



1x



1x



1x

7



1



2



3






1x



2x

8







2x




2x

9





10





11







CITY



60076



60074



60073



60072

LEGO.COM/CITY

LEGO CITY



60110



60109



60108



60107



60106



60105

 LEGO.com/city



CITY



60079



60080



60078



60077

LEGO.COM/CITY



club™

1



LEGO.com/club

2



3





1x
300301



1x
4181142



1x
614301



5x
302301




3x
4565324



2x
302201



4x
379501



1x
4144012

22



2x
6054551



2x
4632566



1x
4535737



1x
6093053



1x
6081986



1x
4659665



2x
301021



2x
300121



4x
407021



2x
366521



6x
366021



2x
6092565



1x
4226876



1x
403221



1x
4298617



2x
6032178



1x
9552



4x
4294734



1x
4600176



2x
6104010



2x
371023



1x
4496366



1x
4164073



3x
306224



2x
4256320



1x
6112623



1x
4506727



2x
362226



2x
6092876



2x
4515373



2x
6047276



2x
4251161



1x
4587844



1x
4560182



2x
366626



1x
379526



1x
303026



2x
4569733



1x
4529064



2x
4297713



1x
4274405



4x
6092570



1x
6024113

1x
6024114

2x
9339

2x
6103414

1x
4298619

2x
4578677

4x
4568644

4x
6064174

1x
292626

1x
400626

2x
6104030

1x
4542671

1x
403228

2x
4167842

2x
4542673

2x
4189801

2x
4646864

2x
4163306

1x
4167504

1x
4599456

4x
4558169

2x
4211549

2x
4211837

1x
4243797

1x
4585947

2x
4211506

4x
4211764

4x
6018081

2x
4210797

4x
4210631

2x
4211043

1x
4211002

1x
4211053

4x
4211063

2x
4566028

2x
4261908

4x
6055350

5x
6051422

1x
4259901

Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346

