




CITY

7213



1




2









1




2



3




4




5




6







9





10






1







3




4





5






7







9



10




11





12






13







14




15





16




17




18



1



2





3





2x

19





21



LEGO

CITY



7241



7942



7239



7208



7207



CITY



3177



3178



3179



3180



3181



3182

©2010 The LEGO Group. 4585174

FREE! GRATIS! GRATUIT!

LEGO club
MAGAZINE™

www.LEGOclub.com



00800 5346 5555*

1-866-534-6258 • 1-877-518-5346

US & Canada only

Canada seulement

* Free phone. Mobile charges may apply. * Numéro sans Frais. Des Frais peuvent s'appliquer avec les téléphones cellulaires. * Gelödt är gratis. Kostan för Användare av MobilFonier kan tillkomma. * Gratis telefonnummer vanaf vaste lijn. * Debet er gratis nummer, når du ringer fra fastlinje. * Det är gratis, när du ringer från en fast telefön. * Det är gratis, när du ringer från en fast telefön.



www.LEGO.com

VISIT THE WORLD'S
BIGGEST LEGO® SHOP!

www.LEGOshop.com