




7030


World City ↑




4209778




1




2




3



1




2




3




4




5





6



7



8




1




2




3




9



10




11







1




2




12





13



14





World City ↑

7030



7031



7035



7032



7033



7034



4511



4512



4513



4514



©2003 The LEGO Group.



www.LEGO.com

